

## Sizing Guide

	SleepWeaver ANEW			Measurement Technique
	Small	Regular	Large	
Nasal Width	1"	1 ¼"	1 ½"	1.) Measure from outer left nare to outer right nare. (see diagram below)
Height	3 ¼"	3 ½"	3 ¾"	1.) Your measurement starts 1/2 inch down the bridge of your nose from between your eyes. (see diagram below) 2.) Your measurement ends half way between the mouth and chin. (see diagram below)

\*If measurement falls between sizes, choose smaller size

\*\*The use of this information is not intended to replace the advice of a medical professional, sleep technician, or HME Dealer.

